Column & Fire Equipment Guidelines **Booth 9900** HALL B Please be aware of building support columns with fire equipment in or around your booth space. General booth guidelines can be found here: https://www.namm.org/exhibit/thenammshow/important-guidelines/display-guidelines-rules-regulations NOTE: Fire equipment must be visible and accessible at all times 9902 702 40' 9701 9800 10000 112 **FIRST AID STORAGE** TEL. REFERENCE GUIDELINES (unless otherwise noted on map) **Building Support Column** FS (Fire Strobe): ACC exhibit hall are 20' height; ACC lobbies are 6'7" height from the floor. FE (Fire Extinguisher): Must remain visible, accessible and unobstructed Exhibitors are free to brand & build around SP (Fire Speaker): 6"x6" & located at 9'9" height from the floor and shall be visible columns, as long as fire equipment is clear and unobstructed and nothing is adhered to the column or FHC (Fire Hose Connection): Must remain visible, accessible and unobstructed FDR (Facility physical building. Door Release): Must not be blocked Utility Floor Ports PLEASE NOTE:

- This diagram indicates the size and approximate position of the obstruction within the booth with measurements. This may vary slightly onsite once the floor has been marked
- All fire equipment on columns must remain visible and accessible at all times and fire hoses must be clear to the aisle.
- Fire alarm devices have a strobe and a speaker at two different heights on a column
- Materials may not be affixed to columns; damage will be billed back to the exhibitor by the Anaheim Convention Center.



