Column & Fire Equipment Guidelines					Booth 4601
Please be aware of building support columns with fire equipment in or around your booth space. General booth guidelines can be found here: https://www.namm.org/exhibit/thenammshow/important-guidelines/display-guidelines-rules-regulations NOTE: Fire equipment must be visible and accessible at all times					
FS 24500 34500 11-9 " 55 , FE		1 1 1 1		47C	
REFERENCE GUIDELINES (unless otherwise not FS (Fire Strobe): ACC exhibit hall are 20' height; FE (Fire Extinguisher): Must remain visible, acces SP (Fire Speaker): 6"x6" & located at 9'9" height f and unobstructed FHC (Fire Hose Connection): Must remain visible Door Release): Must not be blocked	ACC lobbies are 6'7" sible and unobstructe from the floor and sha	ed all be visible		Building Support Exhibitors are free to bran columns, as long as fire e and nothing is adhered to physical building.	nd & build around equipment is clear
 PLEASE NOTE: This diagram indicates the size and approxim with measurements. This may vary slightly or All fire equipment on columns must remain vi must be clear to the aisle. 	site once the floor ha	as been marked			

- Fire alarm devices have a strobe and a speaker at two different heights on a column Materials may not be affixed to columns; damage will be billed back to the exhibitor by the Anaheim Convention Center. ٠



EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. HOWEVER, NO WARRANTIES, EITHER EXPRESSED OF IMPLIED, ARE MADE WITH RESPECT TO THIS FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE FACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE RESPONSIBILITY OF THE EXHIBITOR TO PHYSICALLY INSPECT THE FACILITY TO VERIFY ALL DIMENSION AND LOCATIONS. ©COPYRIGHT 2007, FREEMAN, ALL RIGHTS RESERVED.